# Masoneilan® Model 8007 and 8008 Electropneumatic Transducers

Specification Data

BS 6500 E

06/03





## **New Nozzle Design Minimises Effect of Vibration**

Model 8007 and 8008 electropneumatic transducers convert a low-power DC signal into a proportional pneumatic signal in the 207 to 1035 mbar (3 to 15 psi), or 414 to 2070 mbar (6 to 30psi) range, as appropriate. They are of the force balance type.

Generally speaking, a signal from the Model 8007 is utilised by a pneumatic positioner or a supply relay of the volume booster type.

Model 8008 is fitted with a relay, which allows the transducer output signal to directly control a valve pneumatic actuator.

These transducers are either direct or reverse action. All that is needed to change the direction of operation is to reverse the connections of the signal leads on the terminal board. These transducers can be installed in any position without affecting their operation, and they are not sensitive to radio waves.

## **Description**

**Casing:** Several mounting plates allow the transducers to be fitted to the yoke of all Masoneilan actuators.

**Enclosure Rating for Non-Explosive Atmospheres :** IP 6X according to EN 60529.

## **Approvals for Explosive Atmospheres**

# ATEX Approvals (94/9/EC Directive) Explosionproof:

II 2 G/D EEx d IIB + H<sub>2</sub>

T6 (Tamb. = -20°C to +68°C)

T5 (Tamb. = -20°C to +80°C)

IP 6X T100°C (Ta +80°C)

N° LCIE 02 ATEX 6088

#### **Intrinsic Safety:**

II 1 G/D EEx ia IIC T6 (Tamb. = -55°C to +40°C) T4 (Tamb. = -55°C to +80°C) IP 6X T125°C (Ta +80°C) N° LCIE 02 ATEX 6058 X

# CSA Approvals (Canadian Standards Association)

Flameproof:

Class I, Group D

# Yugoslav Approvals (S Commission)

**Intrinsic Safety:** 

SIA IIC T6 (Tamb.  $\leq$  +40°C) SIA IIC T4 (Tamb.  $\leq$  +80°C)


Particulars contained in this publication are for general information only and Masoneilan reserves the right to modify the contents without prior notice. No warranty either expressed or implied is either given or intended.

**Tropicalisation**: the purpose of this treatment is to protect the transducer from the effects of damp, i.e. fungus and micro-organisms.

**Beam Support**: the beam is supported on a friction free fulcrum provided by two beryllium copper flexure bearings.


Nozzle: this has been designed so that vibration will have no effect on transducer response.

Fig. 1: Nozzle Assembly



**Relay** (Model 8008 only): a diaphragm unit separates the output and nozzle circuits. A double-seated valve controls the flow of supply air to the output and from the output to the exhaust orifice. Supply air enters the nozzle circuit via a metering tube. If necessary, the orifice can be cleared by the manually operated plunger.

Fig. 2 : Relay



#### **Electrical Circuit:**

The input circuit of Model 8007 and 8008 transducers can be adapted to suit DC signals from most electrical controllers. Signal leads are taken into the casing through a 1/2" NPT tapped hole. This connection will accept a cable gland complying with the relevant protection standard.

**Coil**: windings are epoxy resin impregnated.

**Pneumatic Circuit:** the transducer supply and output connections are tapped 1/4" NPT. They are located on the manifold on Model 8007, and on the relay on Model 8008.

To facilitate pneumatic circuit connection, manifold and relay can be fitted to the transducer in a choice of four different positions.

## **Operation**

Any variation in the control input signal through the coil changes the gap between flapper and nozzle, causing a change in nozzle back pressure. This change in pressure works in counteracting beam movement until equilibrium is restored. Output pressure is the same as nozzle circuit pressure in Model 8007 transducers.

With direct action, any increase in the input signal brings about an increase in output air pressure. With reverse action, any increase in the input signal brings about a decrease in output air pressure.




Fig. 3: Sectional View of Transducer (Model 8007 illustrated)

Model 8008, with relay: Supply air enters the circuit via a metering tube. When the flapper blocks off the nozzle, pressure in the nozzle circuit rises. The resulting force moves the diaphragm unit in the direction of the relay plug, and this movement blocks off the vent to atmosphere and releases the supply orifice in the direction of the output. The action of the resulting increase in pressure is to move the diaphragm unit away from the relay plug.

When forces generated by the nozzle and output circuits balance each other, the relay plug no longer allows supply air into the output circuit. A small bleed between supply and output is in fact provided for, and this keeps the relay plug slightly clear of its seat in order to speed up transducer response.

#### **General Data**

**Electrical Circuit**: Resistance of the standard circuit is 216 ohms for a 4 to 20 mA signal (direct current). Some models can be adapted to suit most signals in present use. For intrinsically safe apparatus, 4-20 mA & 216 ohms only. Please see table opposite.

#### **Pressure Table:**

Transducer	Supply Pressure		Output Signal Pressure	
	mbar	psi	mbar	psi
Model 8007	1586	23	207 to 1035	3 to 15
Model 8008	1586	23	207 to 1035	3 to 15
	2413	35	414 to 2070	6 to 30

Control	Transducer	
Input	Input	
Signal	Resistance	
mA	ohms	
1-5	2753	
4-20	216	
10-50	105	
Other signals	To order	

#### **Air Consumption:**

Transducer	Output Signal	Max. Consumption (Steady State)	Max. Instantaneous Flow Rate
Model 8007	207 to 1035 mbar (3 to 15 psi)	0.30 std. m <sup>3</sup> /h (0.18 scfm)	0.30 std. m³/h (0.18 scfm)
Model 8008	207 to 1035 mbar (3 to 15 psi)	0.45 std. m³/h (0.26 scfm)	4.30 std. m³/h (2.53 scfm)
Widdel 6000	414 to 2070 mbar (6 to 30 psi)	0.60 std. m³/h (0.35 scfm)	9.00 std. m³/h (5.30 scfm)

#### **Working Temperature:**

(Refer also to the marking of the apparatus)

Model 8007: -20°C to +80°C

-55°C to +80°C (optional).

Model 8008 (standard : Neoprene type polydiene cloth-reinforced membrane) : -20°C to +80°C. Model 8008 (low temperature instrument : silicon cloth-reinforced membrane) : -55°C to +60°C.

Air Connections: 1/4" NPT.

**Effect of Supply Pressure**: For a supply pressure of 1586 mbar (23 psi): 0.75% of output span for a supply pressure variation of 100 mbar (0.5% per psi).

#### **Performance Data:**

Hysteresis: 0.8% of output span. Sensitivity: 0.5% of input span.


Accuracy: ± 1%.

Performance of a system comprising of valve, packing, actuator, transducer and fittings depends on the individual performance of each component.

Breakdown Voltage Test: 500 VAC (1 min test).

**Dimensions**: see Figure 4. **Net Weight**: 3.5 kg (7.7 lbs).

Fig. 4 : Dimensions (in mm)



#### **BELGIUM**

Dresser Valves Europe 281-283 Chaussée de Bruxelles, 1190 Brussels Telephone + 32.2.3440970 Fax + 32.2.3441123

#### BRAZIL

Dresser Industria e Comercio Ltda. Rua Senador Vergueiro, 433 09521-320 Sao Caetano Do Sul, Sao Paulo Telephone + 55.11.453.5511 Fax + 55.11.453.5565

#### **CANADA**

#### Ontario

Dresser - Masoneilan - DI Canada Inc. 5010 North Service Road, Burlington, Ontario L7L 5R5 Telephone + 1.905.335.3529 Fax + 1.905.336.7628

#### Alberta

Dresser - Masoneilan - DI Canada Inc. Suite 1300, 311-6th Ave., S.W., Calgary, Alberta T2P 3H2 Telephone + 1.403.290.0001 Fax + 1.403.290.1526

#### **CHINA**

#### Dresser

Suite 2403, Capital Mansion, 6 Xinyuannan Rd. Chao Yang District, Beijing 100040 Telephone + 86.10.64661164 Fax + 86.10.64660195

#### **FRANCE**

Dresser Produits Industriels S.A.S. 4, Place de Saverne, 92971 Paris la Défense Cedex Telephone + 33.1.49.04.90.00 Fax + 33.1.49.04.90.10

Dresser Produits Industriels S.A.S. 55, rue de la Mouche, 69540 Irigny (Lyon) Telephone + 33.4.72.39.06.29 Fax + 33.4.72.39.21.93

#### **GERMANY**

Dresser Valves Europe GmbH Heiligenstrasse 75, 41751 Viersen (Dülken) Telephone + 49.2162.81.700 Fax + 49.2162.81.70.200

Dresser Valves Europe GmbH Uhlandstrasse 58, 60314 Frankfurt Telephone + 49.69.439350 Fax + 49.69.4970802

#### **INDIA**

Dresser Valve India Pvt. Ltd. 305/306 "Midas" Sahar Plaza, Mathurdas Vasanji Road J.B. Nagar, Andheri East, Mumbai - 400059 Telephone + 91.22.28351134 Fax + 91.22.28354791

Dresser Valve India Pvt. Ltd. 205, Mohta Building, 4, Bhikaiji Cama Place New Delhi - 110066 Telephone + 91.11.26164175 Fax + 91.11.26165618

#### ITALY

Dresser Italia S.r.l. - Masoneilan Division Via Cassano, 77 - 80020 Casavatore, Naples Telephone + 39.081.7892111 Fax + 39.081.7892208

#### JAPAN

Niigata Masoneilan CO. Ltd. 20th Floor, Marive East Tower, WBG 2-6 Nakase, Mihama-Ku, Chiba-shi, Chiba 261-7120 Telephone + 81.43.2979222 Fax + 81.43.2991115

#### KOREA

Dresser Korea Inc. 2107 Kuk Dong Building 60-1, 3Ka, Choongmu-ro Chung-Ku, Seoul, 100705 Telephone + 82.2.274.0792 Fax + 82.2.274.0794

#### **KUWAIT**

#### Dresser

Middle East Operations, 10th Floor, Al-Rashed Complex, Fahad Salem Street, P.O. Box 242, Safat, 13003 Telephone + 965.9061157 Fax + 965.3718590

#### **MALAYSIA**

Dresser Flow Solutions Business Suite, 19A-9-1, Level 9, UOA Centre, nº 19, Jalan Pinang, 50450 Kuala Lumpur, West Malaysia Telephone + 60.3.2163.2322 Fax + 60.3.2163.6312

#### **MEXICO**

Dresser Valve de Mexico, S.A. de C.V. Henry Ford n° 114, Esq. Fulton, Fracc. Industrial San Nicolas, 54030 Tlalnepantla, Estado de Mexico Telephone + 52.5.310.9863 Fax + 52.5.310.5584

#### THE NETHERLANDS

Dresser Valves Europe Steenhouwerstraat 11, 3194 AG, Hoogvliet Mailing address: P.O. Box 640, NL3190 AN Hoogvliet RT Telephone + 31.10.438.4122 Fax + 31.10.438.4443

#### NIGERIA

Dresser Flow Solutions Plot 293, Akin Olugbade Street Victoria Island, Logos, Nigeria Telephone + 234.1.555.4229 Fax + 234.1.555.7969

#### **RUSSIA**

DS Controls 61, Nekhinskaya Street, Veliky Novgorod 173021 Telephone + 7.8162.157898 Fax + 7.8162.157921

#### **SAUDI ARABIA**

Dresser Al Rushaid Valve & Instrument CO. P.O. Box 10145 - Jubail Industrial City 31961 Telephone + 966.3.341.0278 Fax + 966.3.341.0696

#### **SINGAPORE**

Dresser Singapore Pte Ltd. 16, Tuas Avenue 8 - Singapore 639231 Telephone + 65.6.861.6100 Fax + 65.6.861.7172

#### **SOUTH AFRICA**

Dresser Ltd., South Africa Branch P.O. Box 2234, 16 Edendale Road Eastleigh, Edenvale 1610 Telephone + 27.11.452.1550 Fax + 27.11.452.6542

#### SPAIN

Masoneilan S.A. C/Murcia 39 C, 08030 Sant Boi de Llobregat, Barcelona Telephone + 34.93.652.6430 Fax + 34.93.661.6444

# Masoneilan Direct Sales Offices

#### **UNITED ARAB EMIRATES**

Dresser - Middle East Operations P.O. Box 61302, Roundabout 8, Units JAO1 & JAO2 Jebel Ali Free Zone, Dubai Telephone + 971.4.8838.752 Fax + 971.4.8838.038

#### **UNITED KINGDOM**

DI UK Ltd. Trevithick Works Gillibrands Estate, Skelmersdale, Lancashire WN8 9TU Telephone + 44.1695.52600 Fax + 44.1695.52662

DI UK Ltd.
Unit 4, Suite 1.1, Nobel House,
Grand Union Office Park, Packet Boat Lane,
Uxbridge, Middlesex UB8 2GH
Telephone + 44.1895.454900
Fax + 44.1895.454919

#### **UNITED STATES**

Northern Region Dresser - Masoneilan 85 Bodwell Street Avon, MA 02322-1190 Telephone + 1.508.586.4600 Fax + 1.508.427.8971

Southern Region Dresser - Masoneilan 2135 Highway 6 South Houston, TX 77077 Telephone + 1.281.496.8100 Toll Free + 1.800.847.1099 Fax + 1.281.596.4222

South Texas Operations Dresser - Masoneilan 4841 Leopard Street Corpus Christi, TX 78408-2621 Telephone + 1.361.877.2414 Fax + 1.361.584.1196

Masoneilan Aftermarket Sales & Service Center 16030 Bear Bayou Drive Channelview, TX 77530 Telephone + 1.281.862.1500 Fax + 1.281.862.1550

Western Region Dresser - Masoneilan 2950 East Birch Street Brea, CA 92821 Telephone + 1.714.572.1528 Fax + 1.714.572.1463



© 2003 All rights reserved